Rechargeable Battery

An optional rechargeable battery is available for your PictureMate® Deluxe Viewer Edition printer. Please use the following part number when ordering the battery: C12C831074. This replaces the battery part number that appears in *Using PictureMate Without a Computer*.

You can purchase the battery from an authorized Epson reseller. To find the nearest reseller, please call 800-GO-EPSON. (800-463-7766). To purchase online, visit www.epsonstore.com (U.S. sales only). In Canada, please call 800-463-7766 for reseller referral.

© 2005 Epson America, Inc. 4/05

CPD-19858
Printed in XXXXXX XX.XX-XX XXX